Magic Level

First use and a safe start

Standard adult version, with shaft and grip, magnetic 7 IRON and DRIVER attachments, and two balls. Basic videos and private access are deferred. You can follow these first-use instructions without them.

1. Identify the parts

The grip is where you hold the aid. The shaft defines a reference plane. The marked 7 IRON and DRIVER magnetic attachments represent two geometries. The two balls have different weights. The heavier ball calls for finer control.

2. Assembly and handling

Choose the marked 7 IRON or DRIVER attachment for your exercise and fit it in its working orientation. On the confirmed version, the shaft prevents it from being fitted the other way around. Correct seating is indicated by the magnets joining and sitting flush. Fit and remove your chosen ball by hand at the marked position. Do not dismantle the main axle, fixed shaft connection, bearing or the part attached to the bearing. If seating is uncertain, or a part is loose or damaged, stop practising and arrange a check with Otakar.

3. Your first task

Start slowly in a clear space, using a shorter movement and without hitting a ball. Follow two connected references, the shaft plane and the orientation of the clubface / leading edge relative to that plane. For clear checkpoints, work through position, check, next position, check, connect, then move more fluidly. Gradually connect the checkpoints and reduce reliance on looking at the aid. This first step needs neither a video nor a login.

Checking and progressing

4. Check your movement

Keeping the ball in place does not by itself prove correct impact or guarantee a straight shot. In motion, the moving ball is not an absolute indication of gravity or a swing spirit level. It shows the state of a system affected by movement and resistance in the construction. Discuss uncertain execution with Otakar. There is no universal number of repetitions, practice duration or time needed to master the task.

5. A safe start

Allow clear space for the whole aid. Practise slowly and with control when using the steel ball, and allow for it falling onto a person or a hard surface. Do not hit a ball with Magic Level. Do not use damaged or loose parts. Do not dismantle fixed components or the bearing assembly.

6. The next step

Progress from slow movement to a shorter and then larger range, less reliance on visual checks, your own awareness of movement, the same intention with a normal club, and finally a check using an actual shot. The amount of practice and the criteria for changing range, speed or complexity are not universally prescribed. A reference full swing is not a safety instruction for using this aid.

Contact Otakar at iam@omg.golf or +420 774 455 599. omg.golf/en/magic-level/